



ax6



bx1




Ex3




AX1

Bx1




Cx1


Dx1



Fx1




Gx1




Hx1


1



2



3



SET-UP INSTRUCTIONS

Maximum weight basket: 4 kg



URBAN OUTDOOR
CABINET BAYSWATER